


Open the magazine window by sliding the window stick forward , add up to 26 pellets.

### Loading pellets



Note: Be sure to insert your foot far enough into the stirrup so that the crossbow cannot slip off your foot when cocking, as this can cause serious harm to you.

2. With the safety in the upward or fire position and your arms locked, pull the string back by standing straight up until you hear a click in the trigger housing.

3. After the string is drawn back, relax string tension slightly to be sure that the string is held securely by the string latch. If the string is not held securely, pull back again until you hear the click in the trigger housing.

### Safety Instructions

1. Always remember to treat your crossbow with the same respect due any other weapon. It can be dangerous and deadly if mishandled.
2. Always check your crossbow thoroughly for worn, loose, damaged or missing parts prior to shooting. This will help you avoid malfunctions and possible injury to you, your crossbow, or someone else.
3. **Never dry fire your crossbow.** This can damage your crossbow and will void your warranty.
4. Never point your crossbow at anything you do not intend to shoot.
5. Never shoot any projectile in your crossbow other than crossbow arrows designed specifically for use with your crossbow,
6. Replace the bow string as soon as it shows any significant sign of wear.
7. Do not leave your crossbow cocked for a long period of time , that will reduce the limb's life.

### Maintenance

2. Put a coat of linseed or tung oil every 6 months.
3. Check cams and string periodically.

### Contact us

EBAY: WILLIAMTELLARCHERYSUPPLIES  
 E-mail: contactus@williamtellarchery.com  
 Website: WWW.WILLIAMTELLARCHERY.COM

### WARRANTY

William Tell Archery crossbow's body and limbs are warranted for a year from purchase.  
 Strings are not warranted but can be ordered through us.



# William Tell Archery



## MAD DOG II

## MULTIFUNCTIONAL CROSSBOW


### What is included:

- Crossbow
- Manual
- 3 short arrows
- 20 steel balls

### Specs.

- Draw weight (tension test ): 115 lbs
- Cam draw : 50 lbs
- Weight: 4.6 Lbs
- FPS : 220
- Stock: Nylon/Catalpa wood
- Limbs : Steel
- Body : Aluminum

1. Mount the limb system in the deck of the body , make sure it is fully assembled .



2. The crossed strings should be inside the barrel as shown in the picture below.



3. Use the bolt provided and insert in the hole below the crossbow's mouth , tight using the Allen wrench .

### Loading your crossbow

1. Place your foot completely through the stirrup. Grab the string in each hand next to both sides of the mainframe.

